
Silky FORESTER 3000•4500

2012.10.25



Ref.	Article nr.	Description
1	KSI027438	blade 380-7.5
2	KZSI2730041	blade cover
3	KZSI27301	plastic insert
4	KSI327003N	blade fixing pipe
5-6-7	KSI310540	boltset
8	KZSI2720432	bolt
9		spring push button
10		push button
11		spring fixing bolt
12-13-14-15		see assembly 16A or 16B

Ref.	Article nr.	Description
16A	KZSI27302	cramp housing (S) assembly
16B	KZSI27303	cramp housing (L) assembly
17	KZSI2730402	rubber sleeve
18	KZSI2730403	rubber sole
19	KZSI2730401	rubber grip tape
20A	KZSI2730022	upper pole Forester 3000
	KZSI2730026	upper pole Forester 4500
20B	KZSI2730023	middle pole forester 3000
	KZSI2730027	middle pole forester 4500
20C	KZSI2730012	lower pole forester 3000
	KZSI2730014	lower pole forester 4500